





- |                                       |                                   |                              |                                    |
|---------------------------------------|-----------------------------------|------------------------------|------------------------------------|
| <b>D</b> Montageanleitung             | <b>GB</b> Assembly Instructions   | <b>CZ</b> Montážní návod     | <b>SK</b> Návod na montáž          |
| <b>FR</b> Notice de montage           | <b>IT</b> Istruzioni di montaggio | <b>HU</b> Szerelési útmutató | <b>RO</b> Instrucțiunile de montaj |
| <b>NL</b> Handleiding voor de montage | <b>PL</b> Instrukcja montażu      | <b>TR</b> Montaj talimatı    | <b>RU</b> Инструкция по монтажу    |

# ASTOR CORNER



GR 1 64x170x98 Ax7 Cx1	GR 2 64x194x105 Bx1
---------------------------------	---------------------------



**Service • Assistenza • Dienstverlening • Serwis  
Servis • Szerviz • Сервисная служба**





Name • Naam • Nazwa • Isim • Название

**ASTOR**

Nr. • No. • Номер

Tур • Type • Тір • Тип

**CORNER**



B

A

C

GR 1  
64x170x98  
Ax7  
Cx1

GR 2  
64x194x105  
Bx1

